

- NOTES:
 ① TIE ROOF DRAINS DIRECTLY TO STORM SEWER LINE
 ② SAW CUT CONCRETE TO BE REMOVED
 ③ MEMBRANE ROOF OVER TAPERED INSULATION
 ④ LIGHTED BOLLARDS

